

POWERFLEX®

PART NUMBER

**PFF19-601, PFF19-901,
PFF3-402**

DESCRIPTION

FRONT WISHBONE FRONT AND REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane Bushes with Zinc-Plated Stainless Steel Outer Shell
- 4 x Polyurethane Dust Covers
- 4 x Stainless Steel Sleeves
- 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original rubber bush from the front wishbone.
2. Clean any dirt and corrosion from the bore of the arm, and file off any sharp edges.
3. Press the polyurethane bush with the outer shell into the arm, with the chamfered edge entering the arm first.

Note: Ensure that the centre-line of the bush is parallel to the inside of the wishbone, as shown in Figure 1.

4. Apply some of the supplied grease to the bore of the polyurethane bush
5. Insert the stainless steel sleeve into the bore of the bush until it sits flush within the bush.
6. Depress the dust cover and place it onto the face of the bush, ensuring there is a good seal between the dust cover and the bush
7. Wipe away any excess grease from the bush.
8. Tension all hardware to manufacturers recommended torque settings.

