



PART NUMBER

PFF85-410

DESCRIPTION

FRONT WISHBONE REAR BUSH

INSTALLATION GUIDE

Product description:

FRONT WISHBONE REAR BUSH - PRESSED STEEL ARM

Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel sleeves
- 1 x grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the old bush from the arm by using a press or cutting the bush out. You will need to make sure that the outer metal shell of the original bush is removed.
2. Clean the hole left in the wishbone, ensuring that the leading edges of the hole are smooth before fitting the new bush.
3. The bush will need to be pressed into position with the smaller diameter being pressed into the radiused opening of the wishbone. Use a small amount of the grease provided around the edges of the hole and press the bush in using a bench vise or workshop press. Ensure that the larger diameter of our bush is sitting against the radiused side of the arm
4. Lubricate the centre stainless steel sleeve with some of the grease provided and insert this into the centre of the bush.
5. It is quite normal for the bush to fit a different way up on each side of the car as sometimes the radiused edge of the hole in the wishbone can face opposing ways.

